


SPEED[®]

Airconditioner Outdoor Stand Floor Model

- **NEAT**
- **COMPACT DESIGN**



- **SMART SOLUTION**



- Extra strong.
- Light weight, easy storage, good vibration & shock absorption.
- Allowable load upto 200 kgs.
- Easy & quick to install on ground surface.
- Supplied with fastening screws and nuts.



DURABLE

Commitment to Durability...

◎ Stand has been passed through various harsh and vigorous tests to check the durability, enhanced by the meticulously designed structure.



Rain

Stand is not affected even by heavy rain.



Wind

Stand along with outdoor unit is normal even in strong winds of Typhoon wind waves.



Harsh Environment

Stand is tested among harsh heat of environment (60°C) to cold (-10°C).

◎ Method of Installation

STEP 1



Place the outdoor on the stand and mark both back sides for the hole in the center.

STEP 2



Turnout the stand and drill 11 mm on mark location.

STEP 3



Turn back the stand and fasten with the outdoor unit.

SPEED AIRCONDITIONERS

F-17, Udyog Nagar Industrial Area, Rohtak Road, New Delhi-110041

Ph.: +91-11- 45657475

E-mail: speedairconditioners@gmail.com